




Cisco Headset 531 and Cisco Headset 532

For Cisco Jabber



Incoming call	Blinking red	●
Active call	Steady red	●
Muted call	Steady red	●



Incoming call	Blinking green	☎
Active call	Steady green	☎
Muted call	Steady green	☎
	Steady red	🚫



High Sound Pressure—Avoid listening to high volume levels for long periods to prevent possible hearing damage.

When you plug in your headset, lower the volume of the headset speaker before you put the headset on. If you remember to lower the volume before you take the headset off, the volume will start lower when you plug in your headset again.

Be aware of your surroundings. When you use your headset, it may block out important external sounds, particularly in emergencies or in noisy environments. Don't use the headset while driving. Don't leave your headset or headset cables in an area where people or pets can trip over them. Always supervise children who are near your headset or headset cables.

For Cisco Jabber

Answer a call

Press  on the USB adapter.

End a call

Press  on the USB adapter for 2 seconds.

Reject a call

Press  twice on the USB adapter.

Adjust your volume

Press **+** and **-** on the USB adapter.

Mute yourself on a call

Press the  on the USB adapter.

Unmute yourself on a call

Press the  on the USB adapter.

Put a call on hold and resume a call

1. Press  on the USB adapter.
2. Optional: Select the call you'd like to resume.
3. Press  on the USB adapter.

Change the audio device in Cisco Jabber for Windows

1. Click  and select **Use my computer for calls**.
2. Click **Audio Options** and select Cisco Headset for each audio field.
3. Click  to hear the volume at its current setting.
You can use the volume and mic sensitivity sliders to adjust your speaker volume and mic sensitivity.
4. Click **OK**.

Change the audio device in Cisco Jabber for Mac

1. Click  and select **Use my computer for calls**.
2. Click **Audio Video/Preferences** and select Cisco Headset for each audio field.
3. Click  to hear the volume at its current setting.
You can use the volume and mic sensitivity sliders to adjust your speaker volume and mic sensitivity.
4. Click **OK**.

For more information, visit:

<https://collaborationhelp.cisco.com>